Assembly of your Hi-Spy Viewing Machine.

Step 1

When you receive your machine it will come in two boxes, one large box and one smaller box.



Open the boxes.



Step 2

The small box contains the base and standing ring already built and the large box contains the built viewer.



Step 3



You will also find three short bolts with two washers each in the package at the bottom of the box. These bolts connect the base to the viewer.



Step 4



Using a piece of the packing around the viewing head to support the tube, turn the base on its side at bottom of viewer as in Photo Assembly 4 and bolt viewer to base as in Photo Assembly 5 Two people, one to steady tube, is preferable.







You are done



